



# DUOYI®

## DY 4015

### AUTOMOTIVE BATTERY TESTER



**Brand new DY4015 Automotive Colored Screen Battery Tester is designed for all 12V and 24V starting lead acid battery. It mainly measures status of the battery and electrical system of vehicle with key features as below. Accurate test result will be obtained by 4-wire Kelvin Test Method, which helps you achieve quick repair to the problems. Also full test print-out result drive you to be professional and trusted at the time you point out the issues to your customers.**

#### Key Features:

- ◆ Four main test result indicate the status of the battery and electrical system of the vehicle: Battery Capacity(Voltage, CCA, Internal Resistance, SOH) / Start-up Load / Charging System .
- ◆ Large colored screen provides gorgeous display.
- ◆ Test and display real time temperature.
- ◆ Full test result printing out with date and time shown in the thermal paper.
- ◆ Available for all 12V and 24V starting lead-acid battery, great compatible with regular flooded, AGM flat plate, AGM spiral and gel batteries, and cover 10 battery rating Standards - CCA, DIN, JIS, EN, IEC, GB, SAE, MCA, BCI, CA.
- ◆ Reverse connection protection and overload voltage protection secure user and avoid any damage of the battery or electrical system of vehicle.
- ◆ Date/Time will be auto-updated in printing screen with 3V 2032 coin battery installed. (coin battery not included)

